GASTEC Instructions for No.185 Hydrazine Detector Tube

FOR SAFE OPERATION:

Carefully read this manual and the instruction manual of your Gastec Gas Sampling Pump.

A WARNING:

- 1. Use only Gastec detector tubes in a Gastec pump.
- Do not interchange or use non-Gastec parts or components in Gastec's detector tube and pump system.
- 3. Using non-Gastec parts or components in Gastec's detector tube and pump system or using a non-Gastec detector tube with a Gastec pump or using a Gastec detector tube with a non-Gastec pump may damage your detector tube and pump system, or may cause serious injuries, or death to the end-user. It will also void all warranties, and guarantees regarding performance and data accuracy.

⚠ CAUTION: If you do not observe the following precautions, you may suffer injuries or damage the product.

- 1. When breaking the tube ends, keep away from eyes.
- 2. Do not touch the broken glass tubes, broken pieces and reagent with bare hand(s).
- 3. The sampling time represents the time necessary to draw the air sample through the tube. The tube must be positioned in the desired sampling area for the entire sampling time or until the flow finish indicator indicates the end of the sampling.

△NOTES: For maintaining performance and reliability of the test results, observe the following.


- Use Gastec Gas Sampling Pump together with Gastec Detector Tubes only for the purposes specified in the instruction manual of the detector tube.
- 2. Use this tube within the temperature range of 0 40°C (32 104°F).
- 3. Use this tube within the relative humidity range of 0 90%.
- This tube may be interfered with by the coexisting gases. Please refer to the table "INTERFERENCES" below.
- 5. The shelf life and storage condition of the tube are marked on the label of the tube box.

APPLICATION OF THE TUBE:

Use this tube for detecting Hydrazine in the air or in industrial areas and for determining the environmental atmospheric condition.

SPECIFICATION:

(Because of Gastec's commitment to continued improvement, specifications are subject to change without notice.)



Measuring Range	0.04 – 0.1 ppm	0.1 – 2.0 ppm	
Number of Pump Strokes	10	5	
Stroke Correction Factor	0.4	1	
Sampling Time	1 minute per pump stroke		
Detecting Limit	0.01 ppm (n = 10)		
Colour Change	Pink →	· Yellow	
Reaction Principle	N2H4 + H2SO4 -	→ N2H4 • H2SO4	

Coefficient of Variation: 10% (for 0.1 to 0.5 ppm), 5% (for 0.5 to 2 ppm)

- ** Shelf Life: Please refer to the validity date printed on the tube box.
- ** Store the tubes in a dark and cool place.

CORRECTION FOR TEMPERATURE, HUMIDITY AND PRESSURE : When the ambient humidity is 0-20% R.H.

Temperature & Humidity: To correct temperature & humidity, use the following chart.

Ī	Dolothio	Temperature								
	Relative Humidity	0°C (32°F)	5°C (41°F)	10°C (50°F)	15°C (59°F)	20°C (68°F)	25°C (77°F)	30°C (86°F)	35°C (95°F)	40°C (104°F)
	0%	1.7	1.68	1.65	1.45	1.25	1.23	1.2	1.1	1.0
	10%	1.6	1.55	1.5	1.35	1.2	1.15	1.1	1.0	0.9
ſ	20%	1.54	1.4	1.35	1.25	1.1	1.0	0.9	0.85	0.76

When the ambient humidity is 30 – 90% R.H.

Temperature: Correct for temperature with the table below:

Tube	True Concentration (ppm)								
Reading (ppm)	0°C (32°F)	5°C (41°F)	10°C (50°F)	15°C (59°F)	20°C (68°F)	25°C (77°F)	30°C (86°F)	35°C (95°F)	40°C (104°F)
2.0	2.6	2.4	2.3	2.2	2.0	1.7	1.6	1.5	1.3
1.5	2.1	2.0	1.8	1.7	1.5	1.3	1.2	1.1	1.0
1.0	1.5	1.4	1.3	1.2	1.0	0.92	0.85	0.79	0.71
0.5	0.80	0.74	0.67	0.59	0.50	0.48	0.44	0.41	0.36
0.2	0.33	0.31	0.28	0.24	0.20	0.19	0.18	0.16	0.15
0.1	0.17	0.16	0.14	0.12	0.10	0.10	0.09	0.08	0.07

Humidity: No correction is required between 30 - 90% R.H.

Pressure: To correct for pressure, multiply the tube reading by

Tube Reading* (ppm) × 1013 (hPa)
Atmospheric Pressure (hPa)

* This value is after other correction(s), if any, are applied.

MEASUREMENT PROCEDURE:

- For checking the leakage of the pump, insert a freshly sealed detector tube into pump.
 Follow instructions provided with the pump operating manual.
- 2. Break tips off a fresh detector tube with the tube tip breaker in the pump.
- 3. Insert the tube into the pump inlet with arrow () on the tube pointing toward the pump.
- 4. Make certain the pump handle is all the way in. Align the guide marks on the pump body with the guide marks on the handle.

- Pull the handle all the way out until it locks at one pump stroke (100 mL). Wait one minute and confirm the completion of the sampling. Repeat the above sampling procedure four more times.
- For smaller measurements less than 0.1 ppm, repeat the above sampling procedure five more times until the stain reaches the first calibration mark.
- Read the concentration level at the interface where the stained reagent meets the unstained reagent.
- If temperature correction and/or humidity correction is necessary, obtain the true concentration by using the correction factor or table. Afterwards multiply the correction factor of pump stroke if necessary.
- 9. If pressure correction is necessary, use the pressure correction formula.

INTERFERENCES:

Substance	Interference	Changes colour by itself to
Amines, Ammonia	+	Yellow

This table of interference gases primarily expresses the interference of each coexisting gas in the concentration range, that is equivalent to the gas concentration. Therefore, the test result may show positive results due to other substances not listed in the table. If more information is needed, please contact us or our distributors in your territory.

DANGEROUS AND HAZARDOUS PROPERTIES:

Threshold Limit Value-Time Weighted Average by ACGIH (2021): 0.01 ppm

APPLICATION FOR OTHER SUBSTANCES:

Substance	Correction Factor	No. of Pump Strokes	Measuring Range
Dimethyl hydrazine	1	5	0.1 - 2 ppm
Methyl hydrazine	6	5	0.6 - 12 ppm

CORRECTION FACTOR:

Detector tubes are primarily designed to measure specific gases. But it is also possible to measure other substances of similar chemical properties with the aid of a correction factor or chart. Therefore, please make use of the correction factor/chart measuring ranges as a reference. For more precise factor please contact your Gastec distributor.

INSTRUCTIONS ON DISPOSAL:

The reagent of the tube does not use toxic substance. When disposing the tube regardless of whether it has been used or not, follow the rules and regulations of your local government.

WARRANTY:

If you have any questions regarding gas detection and the quality of the tubes, please feel free to contact your Gastec representatives.

Manufacturer: Gastec Corporation 8-8-6 Fukayanaka, Ayase-City, Kanagawa 252-1195, Japan https://www.gastec.co.jp/ Telephone +81-467-79-3910 Facsimile +81-467-79-3979 IM00185E3 Printed in Japan 21D1Z